DIGIMERGE™
A better way to a secure future

Digimerge Routers Manual

Routers configuration Guide for Digimerge Digital Video Recorders and Network devices

Digimerge Technologies Inc.
300Alden Road • Markham • Ontario • Canada • L3R4C1
tel: (905)946-8477 • fax: (905)947-0138

Table of Contents

INTRODUCTION. **4**

THE ROUTER CONFIGURATION 4
PORT FOWARDING AND DMZ OPTIONS 5
BEFORE YOU START 5
1. THE PORT FORWARDING RULES. *5*
2. THE DMZ feature. *6*

LIST OF PORTS FOR DIGIMERGE NETWORK DEVICES **7**

ROUTERS SECTION **8**

LINKSYS **9**

BEFDSR41W, BEFN2PS4, BEFSRU31, BEFSRU31, BEFSR41 V1& V2, BEFSR V2FW 1.40.2, BEFSR41 V3 V4 & V5, BEFSR81, BEFSX41, BEFSX41-CA, BEFVP41 V1&V2, BEFVP41-CA, BEFW11S4, BEFW11S4 v2,v3, & 3.2, BEFW11S4 V4, BEFW11S4-CA v2 & v4, WRT51AB, WRT55AG 9

LINKSYS. WIRELESS **11**

BEFSR41-CA, BEFSX41 V1.50, BEFW11S4 v1.50.10, BEFW11S4 v1.50.14, RT31P2, WAG54G, WRK54G, WRT54G, WRT54G v1.1 v2 & CA, WRT54G v2.04, WRV54G, WRV54G-CA 11

DLINK **13**

MODELS DI-514, DI-524, DI-604, DI-614+, DI-624, DI-704P (REVB), DI-704P (REVC), DI-704UP, DI-707P, DI-714P+, DI-754, DI-764, DI-774, DI-784, DI-804HV, DI-808HV, AND DI-824VUP: 13

SMC **14**

2804WBRP-G, 2804WBR V1, V2, 7804WBRB 14

ACTIONTEC **15**

GT701-WG, GT704WR, R1020S, R1020S(U), R1520SU, R1524SU-1 15

NETOPIA **17**

CAYMAN 3300 17

WESTELL DSL MODEM/ROUTER **19**

B90-2200- 30-05 (BELLSOUTH) 19
2200 (VERIZON) 22
VERSALINK 327W 22

BELKIN **24**

F5D5231-1 24

NETGEAR **26**

RP614v1 & v2, WGR614, WGT624v1 & 2, ... 26
DG824M V1.3 27

2 WIRE **28**

1000HW, 1000S, 1000SW, 1800HG 28

Digimerge Routers Manual

ZOOM **30**
X4 5551 30
EFFICIENT (SIEMENS) **32**
SPEEDSTREAM 5100,5200, 5400, 5500 32
ZYXEL **33**
ZYWALL1, ZYWALL2WE, ZYWALL2, ZAWALL10, ZYWALL100 33
UNICOM WIRELESS **34**
GIGAFAST **35**
EE-400-R 35

APPENDIX A **36**
HOW TO ACCESS THE ROUTER CONFIGURATION SCREEN 36

APPENDIX B **37**
SELECTING AND ASSIGNING AN IP ADDRESS FOR YOUR NETWORK DEVICE. 37

TROUBLESHOOTING **39**

Digimerge Routers Manual

INTRODUCTION.

The purpose of this manual is to help distributors, installers and customers in general to configure their routers for use with **a network device** such a digital video recorder, video server etc. Our goal is to provide enough information to configure the router and successfully connect to the cameras over the internet. This manual shows most common router models on the market. If your router it is not listed in the manual identify the other routers listed and see if there is a similar one. Let us know if your router is not listed so we may add it in future revisions.

THE ROUTER CONFIGURATION.

The router configuration screen is the last step in the process to view and access the cameras over the Internet (WAN). The connection and configuration will depend from the network topology, configuration and environment. Most digital video recorders and Network devices commonly are connected in a Local Area Network (LAN) and the Router is connected usually to a DSL modem or cable modem. The Router configuration is vital to connect properly to the internet and view the cameras from a remote location.

ROUTER with a 4 ports switch in a WAN / LAN environment.



Router : *A router is a device that forwards data packets along networks. A router is connected to at least two networks, commonly two LANs or WANs or a LAN and its ISP network. Routers are located at gateways, the places where two or more networks connect, and are the critical device that keeps data flowing between networks and keeps the networks connected to the Internet. When data is sent between locations on one network or from one network to a second network the data is always seen and directed to the correct location by the router. They accomplish this by using headers and forwarding tables to determine the best path for forwarding the data packets; and they use protocols such as ICMP to communicate with each other and configure the best route between any two hosts. The Internet itself is a global network connecting millions of computers and smaller networks — so you can see how crucial the role of a router is to our way of communicating and computing.*

Digimerge Router Manual

PORT FOWARDING AND DMZ OPTIONS

Before you start working with your router is important to :

1. Assign a **static IP address** and select the ports to your **network device**(*) , (See **Appendix B** for more information).
2. Have ready your **router (gateway) IP address** to access the router menus (See **appendix A** for more information).
3. Have the **port list** ready according with your product needs to create the forwarding rules. (See page 7 with all products listed).

The information provided in this manual is to guide and help the customer create **forwarding rules or port forwarding for** specific ports on a router.

There are to ways to work with the router ports. The procedure may vary with the router manufacturer option screens. The two options are:

1 . PORT FORWARDING RULES
2. THE DMZ

1. THE PORT FORWARDING RULES.

In order to allow users to access your **Network Device (*)** on the Internet (WAN) we need to create forwarding rules . That means we need to open ports on the Router and forward (Port forwarding) the data from a specific IP address . Once the Router has the ports opened the data will pass-through the Router . Every router internally works and interacts with two IP addresses. One is the internal IP address or gateway. The one works with your LAN and the other one is the external IP for the internet communications.

When a **Network Device** sends data to a remote router on the internet , the router receive the information and needs to know what to do with the data. The port forwarding feature what it does is to tells the router where to send the data with the computer or network device attached to the LAN.

*(*)**Network device**: Any IP addressable device or electronic equipment connected in a LAN such a Digital video recorder, video server or computer.*

When you create and enable the ports on the router (**The term is referred as *forwarding rules***) , the router takes the data off the external **IP address:port** number (this is called a socket) and sends that data to an internal **IP address:port** number. The port forwarding rules are created per port.

Example using port 2000 : When the router receives the data from the ***external IP address***, the router works with the internal **NAT** (Network address translation) and communicates the information from the external IP to the internal IP address. The information from a distant **router** comes with a specific

Digimerge Routers Manual

forwarding rule and that rule contains information related to port 2000. That means the **internal IP address** (gateway) on your LAN will communicate only with the **network device on the LAN** configured to receive the data for port 2000. If you have one **network device** working with port 2000, only this device will be able to use port 2000. That means only a port number can be used for a program or network device. For example if you have a customer using 2 video servers connected on the same **LAN** , you have to give each one a different port to communicate on the same network or over the internet.

2. **THE DMZ feature**. (demilitarized zone)

This feature allows you to open all the ports at once in your router for your **Network device** IP address. The DMZ takes the IP address of the device on your network and forwards all ports. This is really a nice feature if you are having problems forwarding ports for some program or device. It can be a life saver if your router will not allow you to properly forward ports. The **Network Device** with the DMZ enabled is now wide open to internet traffic. If the network device attached to the router is a Digital video recorder or a Video server for example , the unit will not be able to catch a virus, or risk being hacked because these units are stand alone and designed with an embedded operating systems. On the other hand there is a risk if you are using a computer instead. If you are **using a computer** on your LAN it is better to **forward the ports** only and not use the **DMZ** option.


The **router #2** is been configured to do **port forwarding** for the port 2000 for the internal IP address 192.168.1.125 on the LAN . The **router # 2** has the port 2000 open. When the user from **router #1** access the video server, the data will go directly to the local IP 192.168.1.125 using port 2000
ROUTER #1
INTERNET
External IP : 24.116.50.6
ROUTER #2
If the user has installed the network viewer application to view the camera .The application will try to access the IP address from **router #2.** (24.116.50.6)
The network viewer application must have the IP from **router #2** address (24.116.50.6) and the port 2000 to view the camera..
Broadband Modem
192.168.1.125:**2000**
Broadband Modem
WAN

This figure shows an example of how a user access a video server/camera from a remote location using the IP from Router #2 and port 2000 on a a PC

For a more detailed explanation of the port forwarding procedures visit :
http://www.portforward.com/help/portforwarding.htm

Digimerge Routers Manual

LIST OF PORTS FOR DIGIMERGE NETWORK DEVICES

FAMILY	MODELS	PORTS	COMMENTS
DGR200 Series	**201, 204**	80, 1080, 2080	**Default port is 80** Fixed port Only one port is needed.
DGN200 Series	**209,** **216**	Any	**Default port is 80.** Only one port is needed. Suggested alternated port : 2000
Video server	**D4202**	Any	**Default port is 80.** Only one port is needed. Suggested alternated port : 2000
DHT300-400 Series	**304,308,316** **404, 409, 416**	4 ports needed	**Default ports are**: 5000-5003
VCD300 Series	**304, 308,** **309**	***TCP Ports*** **Log On** . 7000 (*) **Live transmission** :8000-8001 (*) **Remote Playback**: 9000-9001 (*) **Automatic connection when alarm is activated** :8003 **Checking server alive**:8002 (*) **Time sync** : 3000-8900 (*) **Two way audio** : 7010-7011-7021 **Web port** : 80,2000 (*) **DDNS Server** : 10101, 43300 (1) ***UDP ports*** 11000 (1)	**Fixed ports.** Web port is 80 and 2000. * Mandatory ports (1)These ports are used to work with the DDNS server
4 channel PCI Video capture card	**QDR0450**	***4 ports needed*** ***Any port from a range from 2000-65000***	**Default ports:** • **Video port** :2000 • **Audio port:** 2001 • **PTZ control** : 2002 • **Remote Search** :2003
4 channel USB video capture card	**QDU470**	***4 ports needed*** ***Any port from a port range from 2000-65000***	**Default ports:** • **Video port** :2000 • **Audio port:** 2001 • **PTZ control** : 2002 • **Remote Search** :2003

Digimerge Technologies Inc. Internal

- Note : Port 80 is the http port for the Internet browser and it is usually blocked by the Internet Service Provider. We recommend using a different port like 2000 to avoid possible problems.

Digimerge Routers Manual

ROUTERS SECTION

This section shows the procedure to create port forwarding rules.
The information is presented by manufacturer and model.

LINKSYS

BEFDSR41W, BEFN2PS4, BEFSRU31, BEFSRU31, BEFSR41 V1& V2, BEFSR V2FW 1.40.2, BEFSR41 V3 V4 & V5, BEFSR81, BEFSX41, BEFSX41-CA, BEFVP41 V1&V2, BEFVP41-CA, BEFW11S4, BEFW11S4 v2,v3, & 3.2, BEFW11S4 V4, BEFW11S4-CA v2 & v4, WRT51AB, WRT55AG

Log in to the Router's Web-based Utility. (This is usually done by opening your web browser, entering 192.168.1.1 in the Address field **(or your "default gateway" IP address from your PC**), and pressing the Enter key. You should see the following screen.

Press the **STATUS** Tab and write the WAN IP address for future reference for the remote connection .

To open the ports press on the **ADVANCE** tab on the top and Select **Port Range Forwarding**


PORT RANGE FORWARDING
Port forwarding can be used to set up public services on your network. When users from the Internet make certain requests on your router, they will be redirected to the specified IP.
Ext.Port
Protocol TCP
Protocol UDP
IP Address
Enable
192.168.1.
UPnP Forwarding
Port Triggering
Apply
Cancel

On the left hand side put the name of the application.

Application name: can be any description of your Network Device attached on you LAN

You are forwarding ports in the **Customized Application** box.

In the **Ext. Ports** box put the port ranges you wish to forward. If you are unsure of the port range/ranges check the Ports list page or the **network device (*)** model you are working with.

Example :
For **port 1080**, start with port 1080, and end with port 1080.

Check on the protocol type **TCP**, **UDP**, or just both. Check both if you are unsure of the protocol type. In the **IP Address** box, enter your **Network device(*)** IP address

Click the **Enable** check box on the right hand side.

If you have more ports continue with the next line.

Click **Apply** at the bottom of your screen to save your changes

(*) See page 5 for more information

DISABLE BLOCK WAN REQUEST FEATURE.

Press the **Advance** tab and select the **Filters** tab.

Click and disable the **Block Wan request** feature.

When finish click on **Apply** to save the changes.



DMZ OPTION

If you don't want to enable the port range forward feature you can use the DMZ option to open all the port at once.

Click on the **Advance tab** on the top

Click on the **DMZ Host** option

Enter your **network device (*) IP address** and press apply.

(*) See page 5 for more information

LINKSYS. wireless

BEFSR41-CA, BEFSX41 V1.50, BEFW11S4 v1.50.10, BEFW11S4 v1.50.14, RT31P2, WAG54G, WRK54G, WRT54G, WRT54G v1.1 v2 & CA, WRT54G v2.04, WRV54G, WRV54G-CA

Log in to the Router's Web-based Utility. (This is usually done by opening your web browser, entering 192.168.1.1 in the Address field **(or your "default gateway" IP address from your PC**), and pressing the Enter key.) You should see the following screen.

Press the **STATUS** Tab and write the WAN IP address for future reference for the remote connection .

To open the ports press on the **Applications and Gamming** Tab on the top. Click on **Port Range Forward** Option

On the left hand side put the name ** of the application. You are forwarding ports in the **Application** box.

***** Application name**: can be any description of your Network Device attached on your LAN*

In the Start and End boxes put the port ranges you wish to forward. If you are unsure of the port range/ranges check the Ports list page or the network device model you are working with.

Example :
For **port 1080**, start with port 1080, and end with port 1080.

Check the protocol type **TCP**,**UDP**, or just both. Check both if you are unsure of the protocol type. In the **IP Address** box, enter your **Network Device (*)** IP address to forward the ports to.

Click the **Enable** check box on the right hand side.

If you have more ports continue with the next line.

Click **Save Settings** at the bottom of your screen to save your changes

(*) See page 5 for more information

DISABLE BLOCK WAN REQUEST FEATURE.

Press the **SECURITY** tab

Click and disable the **Block Wan request** feature.

When finish click on **Save Settings** to save the changes.

DMZ OPTION

If you don't want to enable the port range forward feature you can use the DMZ option to open all the port at once.

Click on the **APPLICATIONS AND GAMMING** Tab on the top.

Click on the **DMZ** option

Enter your **local network device IP address** and press **Save Settings**

Digimerge

DLINK

Models DI-514, DI-524, DI-604, DI-614+, DI-624, DI-704P (revB), DI-704P (revC), DI-704UP, DI-707P, DI-714P+, DI-754, DI-764, DI-774, DI-784, DI-804HV, DI-808HV, and DI-824VUP:

Open your web browser and enter the IP address of your router (192.168.0.1). Enter username (admin) and your password (leave blank).


D-Link
DI-604
Ethernet Broadband Router
Home
Advanced
Tools
Status
Help
Wizard
WAN
LAN
DHCP
Setup Wizard
The DI-604 is an Ethernet Broadband Router ideal for home networking and small business networking. The setup wizard will guide you to configure the DI-604 to connect to your ISP (Internet Service Provider). The DI-604's easy setup will allow you to have Internet access within minutes. Please follow the setup wizard step by step to configure the DI-604.
Run Wizard
Help

Press the **STATUS** Tab and write the WAN IP address for future reference for the remote connection .

To <u>open the ports</u> press on the **ADVANCE** Tab on the top. Click on **Virtual Server** Option

Enter the name of the service (Ex. Your DVR description) you are trying to forward ports for in the **Name** box.



Enter the private **network device (*) IP address** into the **Private IP** box.

Select the protocol type from the **Protocol type** drop down box. If you are unsure of the protocol type select both if available. If both is not an option you would need to create a duplicate configuration, one with TCP selected the other with UDP selected.

Enter the private port into the **Private Port** box. Generally you should enter the same port into the **Public Port** box. For port information check the Ports list page or the ***Network Device*** (*) model

Example using port 1080 :

- *Private Port 1080*
- *Public Port 1080.*

The schedule should be set to **Always**. Put a dot in the **Enable** circle at the top to enable your profile.
If you have more ports continue with the next line.
Click **Apply** at the bottom of your screen to save your changes.

DMZ OPTION

If you don't want to **enable the ports** feature you can use the **DMZ** option to open all the ports at once.

Click on the **Advance** Tab and Select the **DMZ** Option.

Enter your ***network device local IP address*** click on **enable** and press **Apply.**

(*) See page 5 for more information

SMC

2804WBRP-G, 2804WBR V1, V2, 7804WBRB

DMZ Option Only

Open a web browser. In the address bar type the IP address of your router. This IP address is **192.168.1.2** by default. Press **enter**

Step 2:
You should now see a login screen and it should be prompting you for a password. We want to log in as administrator, so enter your administrator password here. By default the administrator password is **smcadmin**. Click the login button to log into the router.

Step 3:
Click **Firewall** on the left hand menu. This will drop down a sub-menu on the left hand side.



Step 4:
Click **DMZ** in the left hand menu. This will open up the screen below.

Step 5:
A Static IP address is need for this function. Click in the **Enable DMZ Yes** radial button. In the **Public IP address** box, you enter the **network device** IP (*) address you wish to open to the internet.

Click **Apply** at the bottom of the page.

Click the **STATUS menu** at the left and write the **WAN Internet IP address** for future reference for the remote connection .

(*) See page 5 for more information

Actiontec

GT701-WG, GT704WR, R1020S, R1020S(U), R1520SU, R1524SU-1

Enter the IP address of your router in the address bar of your browser.. By default the IP address should be set to 192.168.0.1.

Click **setup/configuration**. You should see the following menu.


Basic Setup
Admin Username/Password
Advanced Setup
Set Up / Configuration
This section will guide you through the configuration of your Cable/DSL Router.
In most cases, only Basic Setup is required. In the event that you can not access the Internet after completing the Basic Setup, it is possible that your Internet Service Provider may require additional configuration.
In this case, use the Advanced Setup process to configure your Cable/DSL Router by clicking on the Advanced Setup option from the menu to the left.
Please click the "Begin Basic Setup" button below to start the basic setup.
Begin Basic Setup

Click **ADVANCE** at the side of the menu. You will see the following menu



Click on Port Forward on the left hand side. You should see the following menu.


Port Forwarding
Some Internet applications require certain ports to be forwarded. Please enter the required port ranges and IP Address of the computer running the application into the space below, then click Add. Click Advanced for more options, or click Next to continue.
IP Port Range
to
Protocol
TCP
IP Address
Add
Remove
List of Forwarded Ports
Advanced ..
Back
Next

Enter the following information :

IP Port Range. Enter a port range.

***Example** : For port 1080, start with port 1080, and end with port 1080.*

- **Protocol** : Select the protocol type , TCP or UDP
- **IP address** : Enter your Network device (*) IP address.

Click on **ADD** to add the settings to the box below.

If you have more ports to open repeat the procedure.

To finish click on **Save and RESTART**

(*) See page 5 for more information

DMZ OPTION.

If you don't want to use the **port forward** feature you can use the **DMZ** option to open all the ports at once

Click **setup/configuration**. You should see the following menu.


Basic Setup
Admin Username/Password
Advanced Setup
Set Up / Configuration
This section will guide you through the configuration of your Cable/DSL Router.
In most cases, only Basic Setup is required. In the event that you can not access the Internet after completing the Basic Setup, it is possible that your Internet Service Provider may require additional configuration.
In this case, use the Advanced Setup process to configure your Cable/DSL Router by clicking on the Advanced Setup option from the menu to the left.
Please click the "Begin Basic Setup" button below to start the basic setup.
Begin Basic Setup

Click **ADVANCE** at the side of the menu. You will see the following menu



Click on **DMZ Hosting** option

DMZ Hosting
Your Cable/DSL Router can be configured to support Online Gaming and Internet Conferencing services on a network computer. To use this feature, enter the IP Address of the computer in the DMZ Host field below.
Warning: Using a computer in DMZ mode opens the computer to outside intrusion, creating a security risk.
DMZ Host IP Address
On
Off
Back
Next

Enter the **Network device** (*) IP address, Then you click in the **On** radial button.

Now click on **Save and Restart** on the left hand side. The following menu should appear.

Actiontec
[Main] [Setup] [Status] [Utilities] [Help]
Configuration
Save and Restart
Please click the Save and Restart button below to save your settings and restart your Gateway.
Save and Restart
Firewalling.com
Copyright 2001-2002 Actiontec Electronics Inc.

To finish click **Save and Restart**.

Click the **STATUS menu** and write the **WAN Internet IP address** for future reference for the remote connection .

(*) See page 5 for more information

NETOPIA

CAYMAN 3300

Enter the IP address of your router in the address bar of your browser.. By default the IP address should be set to 192.168.1.254.

Enter your user name and password. By default the username is **admin**, and the password is blank. Click the **OK** button to log in to your router.



Click the **Expert Mode** link on the left hand side of your screen.


Expert Mode Confirmation
You are now entering Expert Mode which is for advanced configuration, management and troubleshooting.
If you change any parameters, the unit may not operate properly.
Click "OK" to continue or "Cancel" to return to the previous screen.
OK
Cancel

Click OK to enter the export mode



- Click on **CONFIGURE** link on the top.
- Click on the **ADVANCE** link


Network Configuration
IP Static Routes Build IP static route table
IP Static ARP Build IP static ARP table
NAT
Pinholes Set up pinholes through NAT
IPMaps Set up NAT one-to-one IP address mappings
Default Server Set up NAT default server options
Services
Differentiated Services Set up Differentiated Service options
DNS Set up DNS options
DHCP Server Set up DHCP server and relay-agent options
RADIUS Server Set up RADIUS server options
SNMP Set up SNMP community, trap and system group options
Access Control Set up Access Control
UPnP Enable or disable Universal Plug'n'Play
LAN Management (TR-064) Enable or disable DSL Forum LAN-Side DSL CPE Configuration services
Ethernet Bridge Set up ethernet MAC bridge
Miscellaneous
System Configure System parameters
Syslog Parameters Set up Syslog
Internal Servers Configure internal web and telnet ports
Software Hosting Set up Software Hosting
Clear Options Restore the Gateway to its factory configuration
Time Zone Time Zone settings
VLAN Setup VLAN Configuration

On the **ADVANCE** Network menu click on the **PINHOLES** Option.

This menu option will allows you to enable the port forwarding option.



Click the **ADD** button to add a new pinhole configuration to your Router.



-**Pinhole Name:** your network device name (ex DVR, video server , or PC)
-**Protocol type**: TCP or UDP
-**External port start** : Enter you start port
-**External port end** : you end port

Example using port 1080.
External start port 1080
External end port : 1080

- Internal IP address: Enter your Network device (*) IP address. (ex DVR , video server or PC attached)

- Internal port :Enter the lowest port.

Example :If you open a range of ports from **80 to 1080**, use 80 as the lowest port.

Click the **Submit** button

If you need to open more ports click on the **ADD** button and repeat the procedure.
(*) See page 5 for more information

If you finished click on the **Alert** button.

The Alert button is a Yellow triangle at the left top area of your menu

Click on **SAVE and Restart**



.

WESTELL DSL MODEM/ROUTER

B90-2200- 30-05 (Bellsouth)

Open a web browser like internet explorer or Netscape

Enter the IP address of your router in the address bar of your browser. By default the IP address should be set to 192.168.1.1.

You should see a box prompting you for your username and password. Enter your username and password now. By default the username is blank, and the password is **NOLOGIN**.
Click the **OK** button to log in to your router.



Click the **Expert Mode** button on the left hand side of your screen.

Then under Home click the **Service Configuration** button on the left hand side of your screen.



In the new menu that appeared under Configuration, click the **NAT** button.



Continue on next page…….

.



Click the **Define Customer Service** button to move to the next page

Custom Service
Set Up a Port Forwarding entry based on your specific ports
Port Fowarding Ranges of Ports
Forward a range of WAN ports to an IP address on the LAN
Trigger Ports
Forward a range of ports to an IP address on the LAN only after specific outbound traffic
next
cancel

Put a dot in the **Port Forwarding Ranges of Ports** radial button. Then click **next** at the bottom of this page



Enter a name for the program or device you are forwarding ports for in the **Service Name** box. Ex : DVR

Enter the ports to forward into the **Global Port Range** boxes.

Example: for port 2000-2000

The smallest port number should go into the box on the left, while the largest port number should go into the box on the right.

Main port the program uses into the **Base Port** box. This is your lower port from your list.

***Examples**: If you are using only one port like 2000 enter 2000-2000.. If your are using a range of port like 80-1080, the base port is 80*

Select the protocol type using the UDP or TCP radial buttons.

Click the **Next** button when you are done making changes.

If you need to add additional ports, click the **Add** button.

When you are done adding ports/protocol types, click the **Close** button

Continue on Next page….

Once you finished adding all the ports go back to the **service** configuration screen



Use the **Service Name** drop down box to find and select the first configuration you just created for your **network device** name (Ex DVR) .

Then click the **Enable** button to enable it. You will need to repeat this step for each service that you created

Once you press enable the following screen will appear



Select and find your **network device (*) IP address** or enter your IP address to forward the ports and complete the procedure,
Press **Done** to finish

(*) See page 5 for more information

Routers Manual

2200 (Verizon)

Versalink 327W

Open a web browser like internet explorer or Netscape

Enter the IP address of your router in the address bar of your browser. By default the IP address should be set to 192.168.1.1

You should see a box prompting you for your username and password. Enter your username and password now. By default the username is blank, and the password is **NOLOGIN**.

Click the **Ok** button to log in to your router.



Click on **Configuration** on the top Menu and Select **Service configuration**

Click the **Define Customer Service** button to move to the next page.

Custom Service
Set Up a Port Forwarding entry based on your specific ports
Port Fowarding Ranges of Ports
Forward a range of WAN ports to an IP address on the LAN
Trigger Ports
Forward a range of ports to an IP address on the LAN only after specific outbound traffic
next
cancel

Put a dot in the **Port Forwarding Ranges of Ports** radial button. Then click **next** at the bottom of this page.



Continue on next page…….

Enter a name for the program or device you are forwarding ports for in the **Service Name** box. Ex : DVR , Video server or PC.

Enter the ports to forward into the **Global Port Range** boxes.

Example: for port 2000-2000

The smallest port number should go into the box on the left, while the largest port number should go into the box on the right.

Main port the program uses into the **Base Port** box. This is your lower port from your list.

***Examples**: If you are using only one port, for example 2000, enter 2000-2000. Your base port will be 2000.*

If your are using a range of port like 80-1080 the base port is 80.

Select the protocol type using the UDP or TCP radial buttons.

Click the **Next** button when you are done making changes.

If you need to add additional ports or you need to specify both protocol types, click the **Add** button. Then repeat the above steps, and specify the other protocol or add another port.

Once you finished adding all the ports go back to the service configuration screen

Use the **Service Name** drop down box to select the first configuration you just created at your device name (Example: DVR) .

Then click the **Enable** button to enable it. You will need to repeat this step for each service that you created

Once you press enable the following screen will appear



Select and find your network device (*) **IP address** or enter your IP address to forward the ports and complete the procedure,
Press **Done** to finish

(*) See page 5 for more information

BELKIN

F5D5231-1

Open a web browser like internet explorer or Netscape

Enter the IP address of your router in the address bar of your browser. By default the IP address should be set to 192.168.2.1.

You should prompted for your password. Enter your password now. By default the password is blank. Click the **Ok** button to log in to your router.

On the left hand side you will see a series of four menus.

In the one titled firewall click **Virtual Servers**. This will bring you to the following menu.

We are going to be working in the table portion of this menu to forward ports. All the settings to forward a port or series of ports will go on one line. If you want to forward additional ports you can fill out a second line with additional information.

Description box. A good description would be the name of the network device (*) (Ex DVR) you are forwarding ports for.

Inbound Port box . Enter the port range. This range would be specified by entering the starting port number in the first box under inbound ports and the ending port number in the second box under inbound ports. Do the same thing for the **Private Port** boxes.

- Type :Select the protocol type **. TCP or UDP or Both** .

***Note** : If you are unsure of the protocol type, just select both.*

Continue on next page…...…

(*) See page 5 for more information

- Enter your network device (*) **IP address** you wish to forward in the **Private IP Address** box.

  - Put a check in the **Enable** checkbox..

Click on **Apply changes** to finish

(*) See page 5 for more information

DMZ Option

On the Setup screen select DMZ at the left area of your menu

You will see the following menu



Enter your Network Device (*) **IP address** and click on **enable**.

Press **Apply changes** to finish

(*) See page 5 for more information

NETGEAR

RP614v1 & v2, WGR614, WGT624v1 & 2,

Open a web browser like internet explorer or Netscape

Enter the IP address of your router in the address bar of your browser. By default the IP address should be set to 192.168.0.1.

You should see a box prompting you for your username and password. Enter your username and password now. By default the username is **admin**, and the password is blank. Click the **Ok** button to log in to your router



The basic settings window will be visible

On the menu bar to the left under **Advanced** click **Port Forwarding**
You should now be at the Port Forwarding menu as shown below.



To create a new port forward **service** click on **Add Custom Service** button.



Enter the information requested on the menu.

- Service Name : Enter the description of your DVR or device or service (PC) . Ex DGR200

-Starting port. Enter the lowest port
-Ending port. Enter the Highest port
-Server IP address: Enter your network device(*) IP address

- Click **Apply** at the bottom of the menu to finish.

(*) See page 5 for more information

DG824M V1.3

DMZ Option

Open a web browser like internet explorer or Netscape

Enter the IP address of your router in the address bar of your browser. By default the IP address should be set to 192.168.0.1.

You should see a box prompting you for your username and password. Enter your username and password now. By default the username is **admin**, and the password is blank. Click the **Ok** button to log in to your router



The basic settings window will be visible

On the menu bar to the left under **WAN Setup Options**

You should see the WAN setup menu



Click on **Default DMZ server** and enter your network device (*) IP address .

Click on **Apply** to Save the settings.

(*) See page 5 for more information

2 WIRE

1000HW, 1000S, 1000sw, 1800HG

Open a web browser like internet explorer or Netscape

Enter the IP address of your router in the address bar of your browser. By default the IP Address should be set to gateway.2wire.net

The basic settings window will be visible



Click on the **FIREWALL** button on the top

Click **FIREWALL SETTINGS** in the firewall menu on the top of the screen



Click the **Add a new user-defined application** link in the Applications section.


Edit Application
Settings
Profile Name
Enter a name for the application profile that you are creating.
Application Name:
Definition
Choose a protocol and enter the port(s) for this application, then click ADD DEFINITION to add the definition to the Definition List. If the application requires multiple ports or both TCP and UDP ports, you will need to add multiple definitions.
Note: In some rare instances, certain application types require specialized firewall changes in addition to simple port forwarding. If the application you are adding appears in the application type menu below, it is recommended that you select it.
Protocol:
TCP
UDP
Port (or Range):
From:
To:
Protocol Timeout (seconds):
TCP default = 86400
UDP default = 600
Map to Host Port:
Default = the same port as defined above.
Application Type:
None (Default)
ADD DEFINITION
BACK

Continue on next page……..

Enter the following information:

-Application name. Enter the name of the program (Ex. Your DVR, video server description).

-Protocol: TCP or UDP.
-Port Range . From (the lowest port)
To (the Highest port)
-Protocol timeout (seconds) :
----For TCP enter : 86400
----For UDP enter : 600

-Map to Host port : Leave it empty
-Application type: Set to None

Click **ADD Definition** to add this definition to your router.

Click the **BACK** button at the bottom page to go back to the previous menu.


System
Broadband Link
Home Network
Firewall
Summary
Firewall Settings
Advanced Settings
HOME | Help | Site Map
Edit Firewall Settings
Settings
By default, the firewall blocks all unwanted access from the Internet. You can allow access from the Internet to applications running on computers inside your secure home network by enabling firewall pinholes. Opening firewall pinholes is also known as opening firewall ports or firewall port forwarding. To do this, associate the desired application with the computer below. If you cannot find a listing for your application, you can create a user-defined application profile. (To create a user-defined profile, you will need to know protocol and port information.)
View firewall details
To Allow Users Through the Firewall to Hosted Applications...
1 Select a computer
Choose the computer that will host applications through the firewall: JOANNASDELL
2 Edit firewall settings for this computer:
Maximum protection – Disallow unsolicited inbound traffic.
Allow individual application(s) – Choose the application(s) that will be enabled to pass through the firewall to this computer. Click ADD > to add it to the Hosted Applications list.
Applications:
All
Games
Audio/Video
Messaging and Internet Phone
Servers
Other
User-defined
Add a new user-defined application
Edit or delete user-defined application
ABC Torrent
Age of Empires
Age of Kings
Age of Wonders
Aliens vs Predator
Anarchy Online
Asheron's Call
Baldur's Gate
BattleCom
Battlefield Communicator
Bit Torrent 2
Black and White
Dark Reign
Dark Reign 2
Delta Force
ADD >
< REMOVE
Hosted Applications:
ABC 1
Allow all applications (DMZplus mode) – Set the selected computer in DMZplus mode. All inbound traffic, except traffic which has been specifically assigned to another computer using the "Allow individual applications" feature, will automatically be directed to this computer. The DMZplus-enabled computer is less secure because all unassigned firewall ports are opened for that computer.
Note: Once DMZplus mode is selected and you click DONE, the system will issue a new IP address to the selected computer. The computer must be set to DHCP mode to receive the new IP address from the system, and you must reboot the computer. If you are changing DMZplus mode from one computer to another computer, you must reboot both computers.
DONE

Select a computer option:. device (your network device(*) IP address) or computer your want to forward.

On the **Applications** list scroll down and find the Application you just created and highlight it.

Click the **ADD** button to move it to the **Hosted Application** box at your right.

Click **DONE** button at the bottom of the screen to finish

Note :If you have multiple ports , you have to create an application for every range of ports

. (*) See page 5 for more information

ZOOM

X4 5551

Enter the IP address of your router in the address bar of your browser. By default the IP address should be set to 10.0.0.3

You should prompt for your password. Enter your password now. By default the password is blank. Click the **Ok** button to log in to your router



Click the **Advanced Setup** button at the top of your screen. You should now see the following screen.



Click the **Advanced Setup** button at the top of your screen. You should now see the following screen

Continue on Next page…….

In the middle of this page you will see a **NAT Options** drop down box. Click the down arrow and select **NAT Rule Entry**



Take note of the **Rule ID's** that are in use.

Usually you want these rule numbers to increment by 10. So the new rule you create should be 10 more than the largest rule number here. At the bottom of the page click **Add**. You should now see another window



Enter the following Settings

1. **Rule Flavor** drop down box. Select **RDR** from the list.
2. Enter a number in the **Rule ID** box. This number needs to be unique, so some number that was not listed on the services page.(any number not listed)
3. **IF Name** box. Select **ALL**
4. **Protocol** drop down box : Select the protocol type of the ports you are forwarding.(if you don't know select ALL)
5. **Local Address From** : Enter your local device network (*) IP address
6. **Local Address To** : Enter your local DVR Ip address
7. **Global Address From:** Enter 0.0.0.0
8. **Global Address To** Enter 0.0.0.0
9. **Destination Port From :** Enter your lower port of your port range
10. **Destination Port To** : Enter the highest port of your port list .
    a. Example 80 - 1080
11. **Local Port** box : Put a zero in it.
12. Click the **Save Changes** button at the bottom of your screen.

Once again click on **Advance setup** button at the top of your screen .Click on the **IP filter button**

The **Security Level** drop down box should be set to none.
The **Private Default Action**, **Public Default Action** and **DMZ Default Action** should all be set to ***Accept.***
Click the **submit** button at the bottom of the page.
Now we are going to save these changes.
Make sure to write your settings to flash, and reboot your router before the settings will take effect.

(*) See page 5 for more information.

EFFICIENT (SIEMENS)

Speedstream 5100,5200, 5400, 5500

Enter the IP address of your router in the address bar of your browser. By default the IP address should be set to 192.168.254.254

Enter your username and password now. By default both the username and password are blank. Click the **Ok** button to log in to your router.



On the main menu click **Login**. Select **admin** from the **username** drop down box. Enter the admin password in the **Password** box. Click the **Okay** button to get back to the main menu..



Select Protocol drop down box. Then enter the port range in the **TCP/UDP Ports** box.

At the right side of the screen enter the lowest port number and highest port number should go in the box on the right.

Example TCP 80 - 1080

Click the **Redirect selected protocol/service to IP address** radio button.

Enter the **IP address** you wish to forward this service to in that box. (your network device (*) IP address)

Then click **Apply** to save your changes.

(*) See page 5 for more information

ZyXEL

Zywall1, Zywall2WE, Zywall2, Zawall10, Zywall100

Enter the IP address of your router in the address bar of your browser.

By default the IP address should be set to 192.168.1.1



You should prompted for your password. Enter your password now. By default the password is **1234**. Click the **Ok** button to log in to your router. In the left hand menu click **SUA/NAT**.

You should now see the following menu.



Enter the following information to open the ports:

-- Check on the **Active** check box
-Name : Enter the name of your network device (Example video server)
-Start Port: Enter your lower port of your list
Example: opening ports from 80 to 1080
--- Start port : 80
--- End Port : 1080
End Port: Enter the highest port

Server IP address: Enter your network device (*) Ip address.

Repeat the procedure to open more ports if needed**.**

Press **Apply** to finish.



UNICOM wireless

DMZ Option only

Enter the IP address of your router in the address bar of your browser.



Enter your User name and password to access the main menu (if needed)



Click on **LAN at** the left side of the menu



Click on **Internet** on the **Advanced** menu at left side of the screen.



To enable the **DMZ** option, click enable on the first line.
Select a PC. Click the drop down menu at the right and locate your network device (*) IP address.
Press **Save** to save the settings

Click On the **Status** menu on the left



Write down your Internet IP address for reference. Press Restart to save the settings

(*) See page 5 for more information

GIGAFAST

EE-400-R

DMZ Option only

Enter the IP address of your router in the address bar of your browser. The default IP address is 192.168.8.1



Enter your User name and password to access the main menu. By default the user name is blank and the password is **admin**.



In the menu on the left hand side of your screen, click **Advanced**. In the menu under Advanced click the **DMZ** link.



By default the DMZ page is disabled. Click the **Enable** radio button.

Enter your Network device (*) IP address on the DMZ menu

Then click the **Save and Restart** button.

(*) See page 5 for more information

Appendix A

HOW TO ACCESS THE ROUTER CONFIGURATION SCREEN .

The Router configuration is the most important step in the process to view the cameras on the Internet. Most of the routers are similar on the access, graphics interface and configuration. The first step to access the router configuration screen it is to know the router IP address or "Gateway". Usually the Web Browser is commonly used to access the router configuration.

If you don't know what is your router IP address (gateway) do the following procedure:

- Press on **Start**
- Click on **RUN**
- Type **cmd** and click OK



DOS command prompt window


C:\WINNT\system32\cmd.exe
Microsoft Windows 2000 [Version 5.00.2195]
(C) Copyright 1985-2000 Microsoft Corp.
U:\>ipconfig
Windows 2000 IP Configuration
Ethernet adapter Local Area Connection:
Connection-specific DNS Suffix . : em.com
IP Address. . . . . : 192.168.1.68
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.1.1
U:\>

In the DOS window type **ipconfig** and press ENTER

The information from your DOS prompt will show you the information related to your network. This information will be:

a- Your computer IP address.
b- Your Subnet mask
c- Your Default gateway.

This information includes the **Default Gateway IP address**. This is the information we need to access the **router menus.** Write down this information for later use.

Once you have the router IP address (gateway), open the Internet Explorer and type in the address bar http://192.168.1.1 and press ENTER

You will see the **LOGIN** screen. Enter the **user name** and **password** to access the Router menus and configuration. (if needed) .

Digimerge Routers Manual

Appendix B

SELECTING AND ASSIGNING AN IP ADDRESS FOR YOUR NETWORK DEVICE.

Selecting an IP address for your **network device** (DVR, Video server , PC) is important. With the IP address you will be able to communicate on the Network properly. To obtain an IP address for your **Network device** try the following options.

1. FROM THE IT ADMINISTRATOR.

1. FROM THE IT ADMINISTRATOR. Medium to large networks are administrated usually by an IT Administrator. In many cases is recommended to ask what IP address can be used on your **network device** (*) *(see page 5 for more information)*

2. THE "GUESSING " METHOD"

If it is difficult to get and IP address for the network , this method will help you to find an IP address easily for your **network device (*) .**

2.1. ADDING A NUMERIC VALUE. First at all, we have to get some information from a computer connected to the same network. See **Appendix A** to see how to get the information off the computer.

Examples.

If the computer connected on the same network has an IP address (example) as 192.168.1.**68** , try adding **5** numbers to the last octet (example , -> **68 + 5 = 73**) . The resulting number will be 192.168.1.**73** .

2.2 CHECKING THE IP ADDRESS . Once we have an IP address we want to try, we have to check if someone is using the IP address before we assign it to the Network device (*).

Go back to the computer at the DOS prompt windows according with procedure on **Appendix A**

On the DOS prompt
Type the following command :

ping 192.168.1.**73**

press **ENTER**


C:\WINNT\system32\cmd.exe
Microsoft Windows 2000 [Version 5.00.2195]
(C) Copyright 1985-2000 Microsoft Corp.
U:\>ping 192.168.1.73
Pinging 192.168.1.73 with 32 bytes of data:
Request timed out.
Request timed out.
Request timed out.
Request timed out.
Ping statistics for 192.168.1.73 :
Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
Approximate round trip times in milli-seconds:
Minimum = 0ms, Maximum = 0ms, Average = 0ms
U:\>

If you receive a **"reply from"** that means somebody is already using this IP address on the network.

*(*) See page 5 for more details…*

Digimerge Routers Manual

Let's try to use another IP address adding another number to the last octet **(lets add 4 numbers, 73 + 4 = 77)** and try again**. Example** 192.168.1.77

Type :
ping 192.168.1.77
press ENTER



If you get a **"request timed out"** , the message means nobody is using the IP address and this means you can use it on your **network device.**

2.3. APPLYING THE SETTINGS. Once we selected the new **IP address 192.168.1.77**, we will need to use the same ***subnet mask*** and the same ***default gateway*** from the computer. In addition to these values we need to make sure what port needs to be assigned to work properly according with the listed ports of your network device. (See page 7 for a complete list).

The final values (example) for the Network device will be:

EXAMPLE

IP address	192.	168.	1	77
Subnet mask	255	255	255	0
Default Gateway	192.	168	1	1

Once you assigned the **IP address** on your network device . Perform a **ping** command to the device according with the ping procedure, If you have a **reply** from your respective device **IP address** that indicates your the connection is working properly on the LAN.



Digimerge Routers Manual

TROUBLESHOOTING

PROBLEM	SOLUTION
I can't access the router configuration screen	• Check your cable connections • Check if you entered the correct router (**gateway) IP address** • Check if your computer has a Firewall blocking the IP address
I can access my router configuration screen but I don't have internet connection	• If you are using a DSL modem, check if you connection is down. Call your ISP to solve the problem.
I opened all the ports on the router and I can't still connect to my remote Network device (DVR, video server)	• Check your DSL modem, make sure your connection is UP. • Check the information on your network device has the correct information: ***IP address, subnet mask and default gateway*** according with the **Appendix A.** • Check if you opened the correct ports.(see page 7) • Check your cable connections. • Call your router manufacturer.
I installed the Network viewer program and entered the WAN IP address I still can't see my cameras	• Check if your computer is using a Firewall application like Norton Firewall. • Check if you configured the correct port to receive the data from your remote location. • If your network device support web browser, try using the IP address and port (if needed) to see the cameras. If you can watch the cameras on your Internet browser, the problem could relate to an Internal firewall application. • Check if your password is correct. • Check if your wan IP address is correct

Digimerge Routers Manual